


Lydon Floor Lamp

Model # 220491



1. Screw pole (B) onto base (A) clockwise until tight.

2. Screw pole (B),(C), (D), and (E) together. You may need to pull any excess cord gently through the base so that these two parts fit.

3. Insert arm (F) onto pole (E) and secure the connection by screwing in hex screw (G) with allen wrench (H).

4. Socket ring comes pre-assembled to the socket. Before placing the shade onto the socket, please unscrew this socket ring.

5. Place shade (J) onto socket (I) and tighten it with socket ring (K).

GENERAL PRODUCT INFORMATION:

This product is suitable for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug as a feature to reduce the risk of electric shock (one blade is larger than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG.**

BULB TYPE:

Max. 150 Watt incandescent bulb (not included) or 16 Watt dimmable LED bulb. Do NOT use 3-way bulbs.

NOTE on LED Bulbs: Use dimmable LED bulbs. Please note that not all dimmable LED bulbs are compatible with a high/low switch. Some dimmable bulbs may have a slight flicker on the low setting. There will be no flicker on the high setting. If using non-dimmable LED bulbs, the low setting will always have a noticeable flicker, and there will be no flicker on the high setting.

***We recommend incandescent bulbs for best dimmable results.**

URBAN BARN