

Ryota Counter Table

Table comptoir Ryota

**URBAN
BARN**

Assembly Instructions / Instructions d'assemblage

Please follow instructions closely as deviation from these instructions may present a possible safety risk and may void your warranty.


It is recommended that assembly is done on a soft surface such as carpet to avoid any damage during assembly.

Suivre attentivement ces instructions. Le non-respect de ces instructions pourrait poser un risque pour la sécurité et invalider votre garantie.

Il est recommandé d'assembler le produit sur une surface souple comme un tapis pour éviter d'endommager le produit pendant l'assemblage.

List of Hardware / Liste du matériel

Ref. / Réf.	Hardware List / Liste du matériel		Qty / Qté
A		Bolt 40 mm / Boulon 40 mm	16
B		Washer / Rondelle	16
C		Allen Key / Clé Allen	1




URBAN BARN


Step 1 / Étape 1

With the table upside down, attach the legs to the tabletop by securing Bolt (A) and Washer (B) using the Allen Key (C).

Placer le dessus de table au sol, à l'envers. Rattacher les pattes au dessus de table; à l'aide de la clé Allen (C), visser les boulons (A) d'abord passés dans une rondelle (B).



Assembled / Table assemblée



URBAN BARN