

Gareth Dining Chair

Chaise Gareth

Assembly Instructions / Instructions d'assemblage




**URBAN
BARN**

Please follow instructions closely as deviation from these instructions may present a possible safety risk and may void your warranty.

It is recommended that assembly is done on a soft surface such as carpet to avoid any damage during assembly.

Suivre attentivement ces instructions. Le non-respect de ces instructions pourrait poser un risque pour la sécurité et invalider votre garantie.

Il est recommandé d'assembler le produit sur une surface souple comme un tapis pour éviter d'endommager le produit pendant l'assemblage.


Ref. / Réf.	Hardware List / Liste du matériel		Qty / Qté
A	Seating / Siège		1
B	Legs / Pattes		1
C	Washer / Rondelle		4
D	Bolt / Boulon		4
E	Allen Key / Clé Allen		1

URBAN BARN


Step 1 / Étape 1

Placed the Seating (A) upside down and attach the Legs (B) using Bolts (D) and Washers (C). Tighten the Bolts with the Allen Key (E).

Placer le siège (A) à l'envers. Rattacher les pattes (B) et sécuriser en vissant les boulons (D) d'abord passés dans une rondelle (C), à l'aide de la clé Allen (E).



Assembled / Chaise assemblée



URBAN BARN